TOP AND CABINET PARTS

For Model: RAS8244LQ0
(Designer White)

AUTOMATIC
WASHER

Roper™
BY WHIRLPOOL CORPORATION



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Model: RAS8244LQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT3956025	Installation Instructions
	LIT3955872	Use & Care Guide
	LIT3956263	Energy Guide
	LIT3954578	Wiring Diagram
2	8271378	Top
3	62750	Spacer, Cabinet To Top (4)
4	357213	Nut, Push−In (2)
5	63424	Cabinet
6	62780	Clip, Top & Cabinet & Rear Panel (2)
7	3357011	Screw, 10−16 x 1/2
8	3356311	Screw & Washer, Lid Switch (2)
11	3949237	Switch, Lid
13	3351355	Screw, Lid Hinge Mounting (4)
15	54584	Hinge, Lid (L.H.)
16	91770	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	21258	Bearing, Lid Hinge (2)
19	3361412	Lid
20	358684	Strike, Lid Switch
22	9724509	Bumper, Lid (2)
28	3390631	Screw, 10−16 x 3/8 (5)
31	90016	Clip, Harness
32	3362952	Dispenser, Bleach

CONTROLS AND REAR PANEL PARTS

For Model: RAS8244LQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS

For Model: RAS8244LQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	3976300	Washer, Water Inlet Hose (4) (1−1/16 x 5/8)
2	9740848	Screw
3		Hose, Water Inlet (2)
	3949374	Blue Coupler
	3949375	Red Coupler
4	3357027	Nozzle−Drain Hose
5	8318255	Strap, Console (2)
6	3357978	Panel, Rear
7	62747	Pad, Rear Panel
8	3951609	Hose, Drain (4 ft.)
	661577	Hose, Drain (9 ft.) (Not Included)
	3357090	Extension, Drain Hose (21 Inches.) (Not Included.)
9	3953146	Timer, Control (60 Hz.) (Motor Not A Service Part)
10	8055003	Clip, Harness & Pressure Hose
11	3351614	Screw, Ground
12	3366847	Switch, Water Level
13	3948608	Bracket, Control
14	661661	Cord, Power
15	3952821	Strain Relief, Power Cord
16	8274437	Cap, End (L.H.) (Console)
17	3400073	Screw, Ground
18	3952164	Valve, Water Mixing
19	3976395	Clamp, Hose
20	303294	Edge Protector
21	370451	Clamp, Hose
22	3357328	Hose, Vacuum Break
23	371503	Clamp, Hose
24	387606	Break, Vacuum
25	3976286	Shield, Capacitor
26	8317940	Drain Hose Assembly
27	90767	Screw, 8−18 x 3/8
28	3366912	Clamp, Hose
30	3363366	Clamp, Hose
31	8317496	Clamp, Hose
32	3951449	Hose, Pump To Tub
33	8318201	Clip, Capacitor
34	661606	Capacitor, Motor Start
35	661614	Switch, Water Temperature
36	3400818	Screw, Timer Mounting
39	3955681	Panel, Console
44	8274390	Knob, Timer
45	8274395	Dial, Timer
47	8274378	Knob, Control
49	388326	Screw, 8−18 x 1.25 (Panel to Top)
50	62863	Screw, 10−16 x 3/8
51	8274434	Cap, End (R.H.)
56	3366913	Clamp, Drain Hose
59	3348424	Shield, Suds
60	3955021	Harness, Wiring (For Detail See Page 9 & 10)

AGITATOR, BASKET AND TUB PARTS

For Model: RAS8244LQ0
(Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Model: RAS8244LQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2	358237	Screw & Washer
3	3348752	Clothes Mover
4	3350389	Spacer, Thrust
5	3347288	Agitator
6	8528150	Tub Ring
7	3359585	Gasket, Tub Ring
8	21366	Nut, Spanner
9	3951989	Basket & Balance Ring
10	3354733	Cap, Barrier
11	63849	Tub
12	3348855	Seal, Inner Cap
13	389140	Block, Drive
14	383727	Gasket, Centerpost
15	3347780	Hose, Pressure Switch
16	3949550	Washer
17	3363663	Cam, Driven
18	3366877	Dog, Agitator
19	3363661	Bearing−Driven Cam
20	3348117	Agitator (Complete)

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Model: RAS8244LQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake & Drive Tube (Complete) (Refer to Page 11 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3951311	Clutch (Complete)
6	3951308	Band & Lining, Clutch (Includes Illus. 7 & 8)
7	62646	Cap, Clutch Spring (2)
8	3946792	Spring, Clutch
9	3360630	Gearcase (Complete) (Refer To Page 12 For Further Breakdown)

Illus. No.	Part No.	DESCRIPTION
10	3357334	Screw, Gearcase To Base (3)
11	62611	Plate, Motor Mount To Gearcase
12	62691	Grommet, Motor (4)
13	285753	Coupling, Motor And Isolation
14	3946532	Shield, Motor
15	3355454	Clip, Anti−Rattle
16	3400516	Screw
17	3349637	Retainer, Motor (2)
18	3362089	Shield, Tub To Motor
19	8528158	Motor, Main Drive
20	3952056	Switch, Main Drive Motor
21	62700	Retainer, Pump (2)
22	3363394	Pump (Complete)
23	3387485	Screw, 10−16 x 5/8

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Model: RAS8244LQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	3400076	Screw, Bracket Mounting (10−32 x 5/8)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring, Suspension (3)
4	3362087	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	63466	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension (Includes Illus. 16)
18	3363660	Pad, Base
19	3946512	Base Assembly (Includes Illus, 6, 7, 8, 9, 16, 17 18 & 26)
21	3359452	Nut, Lock (3/8−16)
22	389102	Foot, Front (2)
23	356934	Seal, Centerpost (2)
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)
25	63134	Ring, Sound Deadening
26	63806	Retainer, Suspension Spring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Model: RAS8244LQ0
(Designer White)



WH2G

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Model: RAS8244LQ0
(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	3349557	Clip, Harness
2	388498	Clip, Harness
3	3347812	Clip, Harness
4	3352501	Clip, Harness
5	90016	Clip, Harness
6	3390496	Clip, Harness
7	389379	Retainer, (Suds Models)
8	352090	Timer, Block Disconnect (White)
9	352089	Timer, Block Disconnect (Black)
10	62889	Receptacle, Terminal (3−Way) (Lid Switch) (Use Term.94613) Or 94614.)
11	353424	Plug, Terminal (3−Way) (Power Cord) (Use Term.94613)
12	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)
13	3348075	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.)
14	3347243	Block, Disconnect (Use Term. 352088)
15	63523	Protector
16	717252	Connector (2−Way) (Use Term.94614)
17	387566	Plug, Terminal (4−Way) (Power Cord) (Use M3 Screws)
18	3352944	Clip, Harness
19	3390423	Block, Disconnect (12−Way) (Timer) (Use Term. 94613)
20	3347730	Receptacle (6−Way) (Use Term. 94613)
21	388818	Plug, Terminal (12−Way) (Use Term. 94613 Or 94614.)
22	3369366	Timer, Block Disconnect (Black) (Amp) (Use Term.3369365)
23	3349494	Connector, Etc
24	60687	Connector, Relay (Use Term.308569)
25	3407125	E.T.C. Control
26	3948617	Connector (T.P.A.) (3−Circuit) (Lid Switch) (Use Term. 3948619 OR 3948620.)
27	3360056	Connector (T.P.A) (3−Circuit) (Pressure Switch) (Use Term.3948619 OR 3948620.)
28	3354925	Block, Connector (Cold Valve) (Use Term.693217)
29	3354926	Block, Connector (Hot Valve) (Use Term.693217)
30	3948615	Connector (T.P.A.) (6−Circuit) (Temp. Switch) (Use Term.3948619 OR 3948620.)

FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

WH2G

BRAKE AND DRIVE TUBE PARTS

For Model: RAS8244LQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	91939	Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Shoe, Brake
9	62703	"T" Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	387806	Spring, Brake
12	62909	Sleeve, Brake Spring
13	63023	Cam, Brake Release
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining

FOLLOWING PARTS NOT ILLUSTRATED

	285208	Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

For Model: RAS8244LQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	3360630	Gearcase (Complete)
2	285202	Cover, Gearcase
3	3349985	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring
10	62676	Spring, Agitate
11	63273	Gear, Agitate (Includes 15 and 29)
12	62619	Washer, Agitate Gear
13	62580	Cam Follower (Includes 14)
14	62581	Cam, Agitate (Includes 13)
15	285509	Shaft, Agitator (Includes 11 and 29)
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389230	Bottom and Pinion, Gearcase
21	285352	Seal, Thrust Plug
22	3351614	Screw, Gearcase Cover, Mounting (8) (10−24 x 3/8)
23	3362552	Ring, Retaining
24	285735	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	3349296	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WATER SYSTEM PARTS

For Model: RAS8244LQ0
(Designer White)



WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)

MISCELLANEOUS PARTS

For Model: RAS8244LQ0
(Designer White)



Illus. No.	Part No.	DESCRIPTION
1	3976263	Miscellaneous Parts Bag
2	3976300	Washer, Inlet Hose (1−1/16 x 5/8) (4)
3	3366912	Clamp, Hose
4	3359452	Nut, Lock (2) (3/8−16)
5	389102	Foot, Front (2)
6	3366913	Clamp, Hose

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH−UP (1/2oz.)		
	72017	White
PAINT, PRESSURIZED SPRAY (12 oz.)		
	350938	Primer, Gray
	350930	White
PAINT, BULK (1 qt.)		
	799344	White (Uncut)

Illus. No.	Part No.	DESCRIPTION
OIL		
	350572	Oil, Gearcase (16 Oz.)
LUBRICANT		
	285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

Illus. No.	Part No.	DESCRIPTION
SEALER		
	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
ACCESSORY PARTS		
	367031	Drain Protector
	285320	Siphon Break Kit